


Lightwave



Installation Manual

Outdoor Smart Socket with Energy
Monitoring (2 gang) (LP42IP)

General Information

Section	Page
Installation Support	3
General Information	4
Product Dimensions.....	5
Technical Specifications	6
Preparing for Installation	7
Installing an Outdoor Smart Socket with Energy Monitoring (2 gang)	8
How to pair an Outdoor Smart Socket to the Lightwave Link Plus App	10
Creating Automations	11
Energy monitoring on the Lightwave Link Plus App	12
Troubleshooting	13
Feedback	15

Installation Support

In this booklet you will find wiring diagrams and instructions on how to set up an Outdoor Smart Socket with Energy Monitoring (2 Gang) (LP42IP)

For further guidance click on the links below:

[Contact the technical support team](#)

[Have a look at our website](#)

[Contact a Lightwave Pro installer](#)


[Phone number: 0121 468 8987](#)

General Information

Note: The socket LED will flash on detecting the insertion or removal of a mains plug

LED Indicator:

Indicator Light changes colour to show the status of the socket (See page 10 for more information)



IP Rating:
IP66 rated when the front cover is closed.

Standby energy use:
Less than 1 watt

Current:
13 A

RF Frequency:
868 MHz


Location:
Make sure that the Link Plus Hub is in a high and central location for optimal communication.

Warranty:
2 years standard warranty (from the date of purchase).


A lifetime warranty on the device is available if you are a Lightwave Plus member.

Voltage and Frequency:
230V ~ 50Hz

High level of protection against ingress from water jets and dust. The durable seals will maintain their integrity over the product's life.



General Information



Height: 154mm
Width: 171mm
Depth: 80mm

General Information

DAMAGE CAUSED BY INCORRECT LOADING, WIRING OR PHYSICAL DAMAGE WILL INVALIDATE YOUR WARRANTY

Please Note:

- Please make sure to isolate the mains before you install your Outdoor Smart Socket with Energy Monitoring
- This device contains sensitive electronic components; ensure that wiring is in accordance with the manufacturer's instructions.
- Please make sure not to wire your socket while it is live, as it will cause the Outdoor Smart Socket with Energy Monitoring to fail.
- If in doubt, please contact our technical team, hire a Lightwave Pro installer, or consult a qualified electrician.

Preparing for Installation

Please follow the electrical wiring instructions carefully to ensure the product is installed safely.

Neglecting to follow these instructions could result in the loss of your 2-year warranty on the device.

Damage caused by incorrect wiring, any modifications or physical damage will invalidate your warranty.

LightwaveRF Technology Ltd cannot accept responsibility for any loss or damage that may occur if the instruction manual is not followed correctly.

IMPORTANT: Any electrical installation must comply with building regulations, BS 7671 (IET wiring regulations) or local equivalent.

IMPORTANT: If conducting an insulation resistance test, any hard-wired Lightwave devices must be disconnected from the mains, or damage to the unit may occur.

You will need:

- Suitable electrical screwdrivers
- Your Link Plus Hub and smartphone
- The Lightwave Link Plus App can be downloaded (available on iOS & Android)
- It is important to isolate the mains before wiring the Outdoor Smart Socket with Energy Monitoring (2 Gang)
- We recommend capturing photographs of your current wiring set up to assist you in properly installing the Outdoor Smart Socket.
- The outdoor use of unprotected, flat PVC-insulated cable is not recommended

What is included in the box:

- Lightwave Outdoor Smart Socket with Energy Monitoring (2 Gang)
- Installation manual
- Outdoor Smart Socket Case

Installing an Outdoor Smart Socket with Energy Monitoring (2 Gang)

If you plan to install this product yourself, please follow the electrical wiring instructions carefully to ensure the product is installed safely, if in any doubt please consult a qualified electrician, technical team or Lightwave Pro installer.

It is important to install this product in accordance with these instructions.

Failure to do so may risk personal safety, create a fire hazard, violate the law and will also void your warranty. LightwaveRF Technology Ltd will not be held responsible for any loss or damage resulting from not correctly following the instruction manual.

Please remember that live electricity is dangerous. Do not take any risks.

Turn off the mains electricity:

It is important to make sure that you turn off the mains power supply to your existing power circuit at the consumer unit.

Location:

An outdoor socket's location should be chosen ensuring adequate access to a mains supply circuit. The circuit must be protected by an appropriate fuse, circuit breaker or RCD.

The surface should be flat, as unevenness could cause product damage or affect operation.

Drain holes **MUST** be drilled out to prevent condensation inside the unit.



Remove the existing switch:

It's a good idea to take a quick photo of the existing wiring configuration so you can easily remember which wires connect to which terminals, especially when there are more than two wires or the labels aren't clear.

Next, unscrew the existing socket and remove the wires. While the wiring is normally colour-coded and follows the diagram in these instructions, some older installations may not match this standard.

Installing an Outdoor Smart Socket with Energy Monitoring (2 Gang)

Be aware that existing cables can vary in colour and may not always be correctly labelled. If in any doubt, always consult a qualified electrician or hire a Lightwave Pro installer.



- Ensure all terminal screws are tight and all wires are neatly routed and not unduly stretched or pinched.
- After wiring the socket, refit the front assembly onto the rear box using the fixing screws—**DO NOT OVERTIGHTEN**.
- Fit screw covers to complete installation.
- Switch power back on, check socket is working and ensure cover and catch is operating correctly. The product is now ready to use.

How to pair an Outdoor Smart Socket to the Lightwave Link Plus App

Before you begin: Download the Lightwave Link Plus App from the Google Play Store or Apple App Store.

Adding a Smart Series Device to the Lightwave Link Plus App:

Before you start, ensure the Link Plus Hub is positioned high and centrally in the house for the best signal.

- Open the app and tap the green plus (+) button at the bottom of the page. Then select the Devices icon.
- Enter a name for your device in the grey box that says e.g. Porch Spotlights.
- Put the device into linking mode (see below). While the device LED is flashing, tap Link in the app.
- The app will scan and pair with the device. Once linked, the LED will flash blue rapidly.

Linking mode:

- Press and hold either button for 5 seconds until the LED flashes red and blue.

Issue with pairing the device:

- If the socket exits pairing mode too soon, press and hold the button again to re-enter.
- If the LED only flashes red, the device memory needs to be cleared (see below).

LED Indicator Lights

-  → Socket is ON
-  → Pairing Mode
-  → Successful Pairing
-  → Memory is Full
-  → Plug-in is Off
-  → Socket is Locked
-  → Socket is updating

How to pair an Outdoor Smart Socket to the Lightwave Link Plus App

Before you begin: Download the Lightwave Link Plus App from the Google Play Store or Apple App Store.

How to master reset the device:

- Press and hold a button until the LED flashes red, then release.
- Press and hold the same button again until the LED flashes red rapidly, then release.
- The LED will turn green and then change to solid red, indicating that the socket is ready to be paired again with the Link Plus App.

For more information, please click on the link:

- [How to fix a smart socket that isn't updating.](#)
- [How to add devices to the Link Plus App](#)
- [How do I master reset Lightwave devices?](#)
- [How to put your devices into pairing mode?](#)

LED Indicator Lights

-  → Socket is ON
-  → Pairing Mode
-  → Successful Pairing
-  → Memory is Full
-  → Plug-in is Off
-  → Socket is Locked
-  → Socket is updating

Creating Automations

Putting the Smart Outdoor Socket into locking mode:

To lock / unlock the socket, press the 'lock' button on the Lightwave App. This means that the manual button will not operate it. A locked socket is indicated by a slow-flashing purple LED when the manual button is pressed.

- Using the Link Plus and Lightwave App, you can create custom automations for the Outdoor Smart Socket.
- As long as the Link Plus Hub is still connected to power, your automations will continue to work even if you lose your internet connection.
- You need an internet connection to create automations.

Types of automations you can create with an Outdoor Smart Series 2-Gang socket:

-  **Timer** = When you would like a device to operate at a set time and on certain days.
-  **Schedule** = It is recommended to use a schedule when you would like a device to operate certain times throughout the week and on specific days.
-  **If-Do** = This automation triggers another action. For example: when one light switches on, all lights in the house turn on.
-  **Group** = This can be used to make multiple devices 'copy' each other. Useful for controlling many devices in the same location by only interacting with one of them.
-  **Do** = Can be used to create moods/scenes. It works on-demand only, so requires execution via the Link Plus App or via Google Home, Apple Home or Alexa.
-  **Simulated Occupancy** = This can be used to schedule your lights to come on at random times throughout the day when you are not at home.
-  **Multi-press** = Gives you the option to trigger an automation to work from a single, multiple, long & release presses.

For more information, please click on the link: [Introduction to Automations](#)

Creating Automations

Putting the Smart Outdoor Socket into locking mode:

To lock / unlock the socket, press the 'lock' button on the Lightwave App. This means that the manual button will not operate it. A locked socket is indicated by a slow-flashing purple LED when the manual button is pressed.


- Using the Link Plus and Lightwave App, you can create custom automations for the Outdoor Smart Socket.
- As long as the Link Plus Hub is still connected to power, your automations will continue to work even if you lose your internet connection.
- You need an internet connection to create automations.

Types of automations you can create with an Outdoor Smart Series 2-Gang socket:

-  **Timer =** When you would like a device to operate at a set time and on certain days.
-  **Schedule =** It is recommended to use a schedule when you would like a device to operate certain times throughout the week and on specific days.
-  **If-Do =** This automation triggers another action. For example: when one light switches on, all lights in the house turn on.
-  **Group =** This can be used to make multiple devices 'copy' each other. Useful for controlling many devices in the same location by only interacting with one of them.
-  **Do =** Can be used to create moods/scenes. It works on-demand only, so requires execution via the Link Plus App or via Google Home, Apple Home or Alexa.
-  **Simulated Occupancy =** This can be used to schedule your lights to come on at random times throughout the day when you are not at home.
-  **Multi-press =** Gives you the option to trigger an automation to work from a single, multiple, long & release presses.

For more information, please click on the link: [Introduction to Automations](#)

Energy Monitoring on the Lightwave Link Plus App



- You can monitor your energy usage on any device connected to the Lightwave Link Plus App.
- For example, you can monitor heating devices, smart sockets, dimmer switches, and more.
- This information will assist you in effectively reducing your energy consumption, enabling you to lower your electricity expenses.
- To save energy, we recommend adding the devices that consume the most power to automations.
- For example, you can put the heating on a schedule throughout the day during winter to help you save money.
- Another example is setting straighteners on a timer so that, if you forget to turn them off, the plug will automatically switch off after a set time.

How accurate is the energy monitoring?

Updates from the energy monitor occur as frequently as every 15 seconds. However, we intentionally restrict the data sent to the server based on current and total values to minimize unnecessary duplication of data. Your live current usage will generally be within 10% of the value displayed when you're away, and the total usage will differ by no more than 0.1kWh. The total usage recorded for yesterday reflects the highest measured value transmitted to the server during that period.

For more information, please click on the link: [Understanding Energy & Cost Monitoring in the Lightwave App](#)

Troubleshooting

If your Lightwave Outdoor Smart Socket isn't behaving as expected, the steps below cover the most common issues and how to resolve them.

● Flashing RED LED Light when linking

A flashing red LED means the device memory is full, usually after a failed pairing attempt.

To master reset the device:

- Press and hold a button until the LED flashes red, then release.
- Press and hold the same button again until the LED flashes red rapidly, then release.
- The LED will turn green and then change to solid red, confirming the socket is ready to be paired again with the Link Plus app.

Helpful Guides:

[How do I master reset Lightwave devices?](#)

✎ Device not linking to the app

- Check the device hasn't been added to the default room (if no room is selected, it goes to the first room automatically).
- Make sure the device is within close range of the Link Plus hub.
- If the LED flashes red when pairing, the device memory is full and will need clearing before it can be added.

Helpful Guides:

[Why Won't My Devices Pair to the Link Plus App?](#)

[Where is the best place to position my Link Plus Hub?](#)

Troubleshooting

If your Lightwave Outdoor Smart Socket isn't behaving as expected, the steps below cover the most common issues and how to resolve them.

Linked but not working

If the device appears in the app but doesn't respond, it may be paired as a Connect Series (Generation 1) device.

What to try:

- Delete the device from the app.
- Clear the memory of the device.
- Put it back into pairing mode.
- Re-add it as a Smart Series device using the name box at the top of the linking screen rather than using "link connect series device"

Helpful Guides:

[How to put your devices into pairing mode?](#)

[How to delete a device from the Lightwave Link Plus app?](#)

[How to add devices to the Link Plus App](#)

Device not linking to the app

- Check the device hasn't been added to the default room (if no room is selected, it goes to the first room automatically).
- Make sure the device is within close range of the Link Plus hub.
- If the LED flashes red when pairing, the device memory is full and will need clearing before it can be added.

Helpful Guides:

[Why Won't My Devices Pair to the Link Plus App?](#)

[Where is the best place to position my Link Plus Hub?](#)

Feedback



We've just launched our new Lightwave installation manuals and would love to hear what you think!

Your feedback helps us improve our guides and provide better support, whether it's something you liked or something we could make clearer. It only takes a few minutes and really makes a difference.

[Please click here to share your feedback](#)

Thank you for helping us improve your Lightwave experience.